

# CARE INSTRUCTIONS

## WASHING INSTRUCTIONS

**IMPORTANT: NEVER DRY CLEAN THIS BLANKET OR USE BLEACH!**

### **MACHINE WASHING**

Disconnect the 10' cord(s) from the bottom of blanket. Place your warming blanket in the washing machine and fill the tub with warm water. Add a small amount of detergent and then let soak for 5 minutes. Agitate on the delicate or gentle cycle for two minutes. Spin on normal speed. Fill the tub for a cool rinse. Agitate for one minute and spin dry. **NEVER** put your blanket through a wringer.

### **HAND WASHING**

Washing your blanket by hand is the best way to make it last. To do this, disconnect the 10' cord(s) from the bottom of the blanket. Wash your blanket separately by hand in a tub of lukewarm (100°F) water using a small amount of mild laundry soap or detergent. Soak the warming blanket for 5 minutes. Next gently work the blanket up and down for five more minutes. **NEVER** rub or scrub. Rinse thoroughly in cool water until all traces of soap or detergent are gone. Squeeze excess water out by hand. **NEVER** twist your warming blanket.

## DRYING INSTRUCTIONS

**IMPORTANT: NEVER USE COMMERCIAL DRYERS AT THE LAUNDROMAT. NEVER PLUG IN YOUR WARMING BLANKET WHILE DAMP. NEVER IRON THE WARMING BLANKET.**

### **MACHINE DRY**

To machine dry, put your warming blanket into a dryer on low heat and allow to tumble until dry. Assure your blanket has enough room to tumble freely.

### **LINE DRY**

You can line dry your warming blanket simply by draping the warming blanket over two parallel clotheslines or a shower rod with the head and foot ends down.

---

## WARRANTY AND REPAIR

### **LIMITED WARRANTY**

Your new warming blanket is warranted to be free from defects in material and workmanship for a period of five years from the date of consumer purchase or receipt as a gift. This warranty does not include damage to the product resulting from accident, misuse, or abuse, including any use contrary to these instructions. If you have any questions about your warming blanket, call us toll free at 1.800.299.1378 between 8 am and 5 pm Eastern Time or email at [custserv@perfectfitindustries.com](mailto:custserv@perfectfitindustries.com).

### **WARRANTY REPLACEMENTS**

If the product should become defective within the warranty period, we will elect to repair or replace it free of charge, including free return transportation. To return the product for repair, pack your warming blanket, control(s), and proof of purchase in a sturdy carton with the control(s) wrapped securely inside the warming blanket for shipping protection. Make sure to tape and secure the box well.

(Please note that damage in transit is not covered by your warranty.) Carefully address the carton to: Perfect Fit Industries, 101 W. Washington St., Loogootee, IN 47553, Attn: Quality Assurance Dept. . Enclose a letter explaining why you are returning the product. In your letter, please be sure to provide full information, such as date and place of purchase, your full name and address, and the service or repairs you desire. Your warming blanket and control(s) will be returned to you in like-new operating condition. Note: This warranty gives you specific legal rights; you may have additional rights that vary from state to state.